



Pro Comp Suspension, Inc. Chula Vista, CA USA

Ph:(619) 216-1444 ● Fax:(619) 216-1474 ● E-Mail: tech@explorerprocomp.com ● Website: www.explorerprocomp.com

INSTALLATION INSTRUCTIONS:

Part # 690001 & 690002 Stem Mount to Eyelet Shock Adapter

Bill Of Materials

Part #	Description	Qty.
90-1079	Shock Adapter	2
OR		
90-3162	Shock Adapter	2
90-6007	Hardware Pack	1
54314	Shock Sleeve	2

Instructions:

- 1) Install shock sleeve into shock eyelet.
- 2) Assemble adapter as shown in Illustration.
- 3) Torque 1/2" bolt to 60 ft. lbs.
- 4) Install into existing stem mount. Rotate adapter until the shock mounting bolts are as close to parallel as possible.
- 5) Torque 5/8" nut to 105 ft. lbs.

