

INSTALLATION INSTRUCTIONS

Part # TJ3FL TJ Front Sway Bar Extensions

- PLEASE READ ALL INSTRUCTIONS FROM START TO FINISH BEFORE YOU BEGIN INSTALLATION.
- Secure and properly block rear wheels prior to installation.
- Check hardware list to assure your kit is complete.

BILL OF MATERIALS:

<u>DESCRIPTION</u>	<u>QTY.</u>
Sway Bar Extensions	2 ea
Sway Bar Link Adapters	2 ea
10 mm x 1.48" Sleeve	2 ea
12 mm x 1.48" Sleeve	2 ea
5/8" Hourglass Bushing	4 ea
3/8" x 2 1/2" USS Ad 5 Capscrew	2 ea
3/8" x 1 1/2" USS Gd 5 Capscrew	2 ea
3/8" USS Flat Washer	8 ea
3/8" USS Nylock Nut	4 ea

INSTRUCTIONS:

- 1) Support front axle on jack stands and remove front wheels.
- 2) Remove factory sway bar links, a tie rod puller or pickle fork may assist in removing tapered mount.
- 3) Install bushing and sleeves into new extensions.
- 4) Install adapters on sway bar using 3/8" x 1 1/2" hardware, do not tighten. See illustration A.
- 5) Install sway bar extension links on to adapter, it will be necessary to rotate adapter to install bolts. Install lower factory bolts and tighten all hardware.
- 6) Replace wheels and turn lock-to-lock to check for interference.

ILLUSTRATION A

