



Revised: 07/23/99

Explorer Competition Products, Inc. Chula Vista, CA USA

Ph: (619) 216-1444 • Fax: (619) 216-1474 • E-Mail: tech@explorerprocomp.com • Website: www.explorerprocomp.com

INSTALLATION INSTRUCTIONS

Part # TJF 600 Jeep TJ Frame Brace Kit

- ❑ PLEASE READ ALL INSTRUCTIONS FROM START TO FINISH BEFORE YOU BEGIN INSTALLATION.
- ❑ Assemble rod ends into support tube.
- ❑ Groove in tube is left hand end. Left hand rod end has a groove in jam nut.
- ❑ Install frame support tube and related components as shown in illustration.
- ❑ Torque 1/2" bolts to 85 ft./lbs. And 9/16" hardware to 105-110 ft./lbs.

BILL OF MATERIALS:

<u>DESCRIPTION</u>	<u>QTY.</u>
1/2"x7 1/2" Bolt	1 ea
1/2"x2 1/2" Bolt	1 ea
1/4" Spacer	1 ea
Rt. Hand Pod End	1 ea
Left Hand Rod End	1 ea
Frame Support Tube	1 ea
1"x1 1/2 Mount Block	1 ea
1/2" Top Lock Nut	2 ea

